

Installation instructions for Uridan water-free urinal model GH-6

Important notes:

- The urinal **must** be installed in accordance with the AS/NZS 3500 Plumbing Requirements
- Ensure that existing sewer pipes are well cleaned and don't have pre-existing blockages
- This Uridan urinal is already trapped. **DO NOT** connect to another trap
- Ensure that noggings and studs are positioned at the appropriate height to allow for fastening of mounting bracket
- Please leave customer care booklet, Uriclean cleaning detergent and hook with customer

Installation process

- Drill the holes for top mounting bracket 835mm from floor.
- Attach bracket to wall ensuring that the top edge of the bracket bends **toward** the wall.
- Rough-in 50mm PVC DWV waste at 350mm from finished floor.
- Attach 50mm 88 degree bend (F&F) and glue in at 107mm centre from wall.
- Glue PVC adapter (supplied) into end of bend and grease rubber seal.
- Position support lower support bracket under bend and secure to wall.
- Slide the urinal down over top bracket ensuring the bottom of the waste trap is secure in the waste outlet.
- Apply silicone sealant around outer edge of urinal and wall if required.

Preparing the urinal for use

- Pour approximately 2 litres of water in the trap, until level with the top of small waste pipe.
- Insert the stainless steel waste cover and then pour 1 bottle of **URILOCK** fluid over the cover.
- Allow to drain and then spray bowl with Uriclean and wipe.

