

Servicing Uridan Waterless Urinals

1. Wearing gloves, remove any rubbish from the urinal.
2. Insert a small screwdriver into the hole in the stainless steel waste cover that is shaped as a slot .
3. Rotate and lift off the stainless steel waste cover.
4. Using a small pair of pliers remove the small pipe in the water lock.
5. Remove uric scale deposits from underneath waste cover and inside the large PVC pipe using a brush.
6. Ensure that the drain holes in the cover are clear.
7. Flush out the waterlock with water to clean out any deposits. Use a brush if necessary.
8. Pour large bucket of water into the bowl to flush out sewer line.
9. Clean uric scale deposits from the small pipe and relocate into the waterlock.
10. Pour in water until it reaches the top of the small pipe.



Barrier for waterless urinals



The Urinal Shop

Your one stop shop for anything to do with urinals and their accessories

www.theurinalshop.com.au

P: 02 9863 0968

11. Replace the stainless steel waste cover.
12. Pour in **300ml of Aqualok** over the stainless steel waste cover .
13. Spray around waste cover with **AquaClean** and wipe with a cloth.
14. The urinal is now ready for use again.

Aqualok is a liquid barrier designed to be used in waterless urinals that have a cartridge design system.

The oil is simply poured into the urinal after the trap cover is in place eliminating odours from the urinal.

Aqualok is replaced every 3months or whenever the urinal trap is cleaned.

Aquaclean microbial cleaner should also be used for daily cleaning. Aquaclean is designed to be used with **Aqualok**.

Aqualok can also be used in floor wastes to prevent odours from coming out of the drain due to stagnant water.

Aqualok is manufactured in Australia.



aqua
LOK

Barrier for waterless urinals



The Urinal Shop

Your one stop shop for anything to do with urinals and their accessories

www.theurinalshop.com.au

P: 02 9863 0968