



TEMPLATE FOR BORONIA HPKV ST 2244

- INSTALLATION GUIDELINES:**
1. Cut out the Screw according to the Dotted Pencil line
 2. Use a sharp pencil and mark the position of the Screw according to the Template.