

# ZeroFlush Waterless Urinal EnviroSeal BioPur Commissioning Instructions

**Before commissioning a BioPur Wonder Wizard Tab in a ZeroFlush urinal with an EnviroSeal operating system:**

- Be aware of MSDS sheets
- Check for visible evidence of any leaks after a water test
- Check there are no blockages in your waste outlet drain



## Step 1

Remove the Enviroseal unit and BioPur holder from the box.



## Step 2

Remove the BioPur holder from the EnviroSeal and push the EnviroSeal into position in the urinal housing. You will feel a click as the O ring locks in. Use your thumbs to push all round the EnviroSeal to create a firm seal against the stainless steel rim.



## Step 3

Unscrew the BioPur holder holding onto bottom of the holder spin the white cover around to remove the BioPur holder from the top cover.



### **Step 5**

Install the new Wonder Wizard Tab into the bottom of the holder. In urinals that are heavily used you can install two new Tabs if needed.



### **Step 6**

Reconnect the top cover together with the BioPur holder and screw the two slightly around to lock into place. Screw the BioPur holder onto the EnviroSeal ensuring it is firmly fixed in place without over tightening.



### **Step 8**

Pour 1 litre of water over the the BioPur holder to activate the new Wonder Wizard Tab. Wipe clean the inside and outside of the urinal with a soft cloth paper towel and the urinal is ready for use.