

INSERT REPLACEMENT



After approximately 15,000 uses, there will be a small amount of Blue Odor Barrier Liquid on top of the Drain Insert. This indicates it is time to change out the Odor Barrier Liquid and the Drain Insert.



1
Screw the key into one of the holes of the Drain Insert and pull upward to remove. When insert is pulled, the contents of the waste trap empties into the waste line.



2
Dispose the Drain Insert and key in a plastic bag.



3
Rinse the trap with two buckets of warm water. If necessary, use a small brush around the stainless steel ring. **Be careful not to scratch the ring.**



4
Take a new Drain Insert and place it in the waste trap.



5
Press down on the drain insert until you feel and hear a slight popping sound. The insert must be tight.



6
Pour about **30 oz. of water** over the Drain Insert. Then slowly pour the **entire contents of the Odor Barrier** onto the Drain Insert. Wipe clean. The ZeroFlush® Urinal is now ready for use.



The Urinal Shop

Sydney - Head Office
1800 URINAL (874625)
(02) 9863 0968
info@theurinalshop.com.au