

PLEASE READ BEFORE INSTALLING

Please note that the timer has been preset and tested.

Settings:

Operational time: 7am - 7pm Flush time: 10 secs 15 mins between flushes 7 days per week.

Once the timer has been installed and plugged in you simply need to press the MODE button once.

OFF should disappear from the screen, the solenoid valve should open instantly and water should flow for 10 secs.

This is all that you need to do.

There is a QR Code in the lid of the unit. If you want to adjust the settings then please scan the QR code and watch the video.

