



# Maintenance Instruction Changing D-Valve



**1.**  
*Remove D-Valve with Service Key counter clockwise and dispose*

**2.**  
*Flush the drain with approximately 10L of water*

**3.**  
*Install the the new D-Valve clockwise using the Service Key*



**4.**  
*Spray urinal with Biox cleaner.*

**5.**  
*Finished!*

*In order to get the best from your waterless urinal it is important that you follow the maintenance instruction above. The D-Valve needs to be changed on average between 2 and 4 times a year depending on usage.*



## The Urinal Shop

Sydney - Head Office  
1800 URINAL (874625)  
(02) 9863 0968  
info@theurinalshop.com.au