

uridan-Cleaning Instructions

Daily Cleaning

uri**CLEAN**

Art.Nr. 618 728 050



uridan can be cleaned very simply with the aid of uri**CLEAN**. Simply spray the urinal surface with uri**CLEAN** and the lotus effect prevents any adhesion of urine drops, causing them to simply roll off.

①



» Spray uri**CLEAN** daily on the cover and surface of the urinal.

②



» Remove and clean the cover every 2 weeks and clean the neck and edge of the urinal with a brush.

③



» Polish the outer and inner surface of the urinal with the uri**CLOTH** cleaning cloth.

* In high traffic amenities, we recommend cleaning the urinal several times a day.

Refilling

uri**LOCK**

Art.Nr. 618 729 030



Our patented biodegradable blocking fluid uri**LOCK** ensures that your uridan urinal remains completely odourless, operating without the need for costly mats, sealants, inserts or chemical additives.



» Pour uri**LOCK** blocking fluid directly over the cover.

* Refilling depending on frequency. (every 1-3 months)

uridan-Cleaning Instructions

Deep Cleaner

uri**STRONG**

Art.Nr. 618 730 030



uri**STRONG** deep cleaner is ideal for heavy and persistent dirt and deposits in sanitary areas. uri**STRONG** also removes lime and urine scale.

The recommended application is 3 to 6 times per year.

①



» Lift cover with suction device.

②



» Pour 100 ml of uri**STRONG** directly into urinal.

» Leave for 5 to 15 minutes. (depending on requirements)

③



» **Flush** with 5 litres of warm water to ensure waste trap clears.

④



» Clean the inside of the waste trap, the edge and neck of the urinal with a brush.

» Flush again. Slowly refill waste trap with water.

⑤



» Insert the cover and pour uri**LOCK** over the cover.