

# Cleaning Instructions



Remove filter



Interior cleaning:  
Spray with BIOX  
cleaner or Urimat



Clean bowl and visible  
black seal with clean  
paper

**Important!**

Do not attempt to remove  
black seal - clean only.



Exterior cleaning;  
Spray with BIOX  
cleaner or Urimat



Then wipe with  
clean paper



Insert new filter or  
cleaned filter



Spray bowl with BIOX  
cleaner and leave.

**Important!** Do not wipe



Finished



BIOX cleaning agent

- biological odour killer
- environmentally friendly
- easy and safe to use
- constant freshness

### BIOX Order #

- 80.001 1 LITRES BIOX CLEANING AGENT CONCENTRATE
- 80.006 10 LITRES BIOX CLEANING AGENT CONCENTRATE
- 80.008 SPRAY BOTTLE BIOX

In order to get the best from your Urimat it is important that you follow the cleaning instructions above on a daily basis.

The use of chemical products are not recommended whilst using BIOX cleaning agent as they will affect the efficiency of the microbiological cleaning properties. URIMAT recommends that you do not use any type of corrosive cleaning product that can damage your urinal and siphon insert.



Sydney - Head Office  
1800 URINAL (874625)  
(02) 9863 0968  
info@theurinalshop.com.au