



ROUGHING IN FOR THE BRACKET AND TRAP POSITIONS

For timber stud walls the noggings and studs must be positioned at a height to allow for the location of the fasteners. The centre position is detailed in Fig 1.

ROUGHING IN FOR THE SPARGE PIPE AND WASTE/DRAIN PIPE

Accuracy is required between the two pipes as detailed in Fig. 1 & 2.

'P' TRAP URINAL INSTALLATION

- Once the roughing in details have been confirmed on the wall as detailed in Fig. 1 & 2.
- Fit the outlet kee seal over the waste/drain pipe spigot protruding from the wall.
- Gently push the urinal 'P' trap onto the kee seal using a soap solution lubricant.
- Centre the trap in the vertical position and mark the three screw holes.
(Note: the top screw hole is offset to the left of centre line by 10mm (3/8") as detailed in Fig. 1.
- Secure the trap onto the wall using suitable fasteners.
- Fix the Leda Urinal Fixing Bracket into position as detailed Fig. 1.
- Fit the inlet kee seal on to the sparge pipe and position the urinal over the pedestal if required ensuring that the sparge pipe is aligned with the kee seal. (Use soap solution lubricant on the seals)
- Push the urinal gently onto the sparge pipe while engaging the outlet into the trap seal.
- Secure the urinal onto the concealed bracket using plastic fixing sleeve into holes in the urinal, screw the two threaded studs into the bracket, as detailed in Fig. 4. Tighten fixing heads with a 7/32" Allen key (not supplied) to mount urinal to wall while ensuring level.

IMPORTANT - DO NOT OVER TIGHTEN, AS THIS MAY CRACK THE URINAL SIDE.
Snap on plastic cap, as detailed in Fig. 4.

- Caulk with an acetic cured silicone sealant/caulking as required.

Note: The urinal must be installed in accordance with the AS/NZS 3500 Plumbing Requirements. Local Authorities have varying requirements.

