

INSTALLATION INSTRUCTIONS

Johnson Suisse Life Urinal

Code J6010 - Back Entry
J6000 - Top Entry



G E M I N I
 JohnsonSuisse

DESCRIPTION

The Life Urinal is a vitreous china wall hung urinal with a waste trap that is concealed within the unit.



This 4 Star WELS rated urinal is designed to be used with an approved flushing device.

The following WaterMark approved flushing mechanisms are recommended - ZIP FlushMaster, Thornthwaite Rado, Enware EMF.

An Easi-fix wall mounting bracket and installation template is supplied.


Both back and top water inlet models are available

A stainless steel waste dome is provided




INSTALLATION STEPS


1. Inspect urinal for any transit damage before starting installation.
2. Check site roughing in and assembly dimensions before starting installation. Check-measure the water inlet/waste outlet and bracket locations to confirm installation fit.
3. Using the wall bolts provided affix the bracket-plate to the wall so that the bolt holes are about 145mm below the water inlet centre. Use the template for ease of locating the fixing points.
4. For back water inlet - ensure that the 19mm copper sparge pipe protrudes 40mm from the finished wall face
 For top water inlet the sparge pipe is fitted after mounting the urinal
5. The waste is fitted to a 50mm DW PVC connector(not supplied)
6. For back water inlet fit the rubber seal into the recess in the back of the urinal,
7. Affix the waste trap to the wall.
8. Mount the urinal on the bracket ensuring the water inlet and waste outlet seal correctly(lubricant may be used).
9. Attach the bolts and rubber cover caps.
10. For top water inlet - fit the rubber seal and insert the sparge pipe (20mm)
11. Fit the waste dome on the VC.
12. Test flush and check for leaks
13. Silicone sealant may be applied to dress and seal the contact between the urinal and the wall



Back Water Inlet
 Model: J6010




Top Water Inlet
 Model: J6000



Note: the 19mm copper sparge pipe is not included

50mm DW PVC connector (not included)



All installations should be carried out by a qualified tradesman in compliance with the national Plumbing and drainage code and any State or Local Authority Regulations